

Tesrix assembling manual

Confirmation before the installation



- Open the box, check the contents of box.



- Tesrix main (× 1)



- Joint (× 4)
- Cap for tesrix main (× 4)



- Joint cap (× 12)
- Bolt M6 (× 4)
- Nut M6 (× 4)
- washer 6 (× 4)
- wood screw 5 (× 12)
- washer 5 (× 12)

Tesrix assembling



Put on a joint tesrix itself with the bolt and the nut and the washer.



Tighten a bolt and a nut by using the tool such as wrench.



Install four joints in total. Set a cap tesrix it self after the joint installation completion.




Tesrix assembling completion.

The hole processing



Set on the installation position.



Ink out is done in accordance with the hole of the joint.



warning

Confirm a hole position punching process precisely. Please process 12 point in total after that.

The hole processing



The hole is vacated in the adaptation drill.

for example

- The hole diameter 8mm
- Depth of the hole 40 ~ 45mm

Install of plug



Get crowded plug.



warning

Be careful not to break a tile!

Screw installation



Screw installation. (An attached thing 5、 L = 40mm screw)



Put 12 places with the screw in total. Please set belonging cap for the joint after the installation completion of screw.

Installation completion.